```
include <Servo.h>
// Define the pin for the rain sensor
const int rainSensorPin = A0;
// Define the pin for the servo motor
const int servoPin = 8;
// Define the pin for the buzzer
const int buzzerPin = 9;
Servo myServo;
bool rainDetected = false;
unsigned long buzzerStartTime = 0;
const unsigned long buzzerDuration = 2000; // Changed to 2 seconds
void setup() {
 pinMode(rainSensorPin, INPUT);
 pinMode(buzzerPin, OUTPUT);
 myServo.attach(servoPin);
}
void loop() {
 int rainState = digitalRead(rainSensorPin);
 if (rainState == LOW && !rainDetected) {
  myServo.write(120);
  digitalWrite(buzzerPin, HIGH);
  buzzerStartTime = millis();
  rainDetected = true;
 }
```

```
// Turn off buzzer after 2 seconds
if (rainDetected && millis() - buzzerStartTime >= buzzerDuration) {
    digitalWrite(buzzerPin, LOW);
}

// Reset servo and rainDetected flag when no rain
if (rainState == HIGH) {
    myServo.write(0);
    rainDetected = false;
    digitalWrite(buzzerPin, LOW); // Ensure buzzer is off
}

delay(100);
}
```